

**WARNING** Risk of fire or electric shock. Only qualified, licensed electricians should install Delray Lighting products.

1. Read and review all instructions and diagrams prior to installation.
2. Disconnect power prior to installation. Turn off circuit breaker or remove fuse from fuse panel. (Turning off the light switch is insufficient to safeguard against electric shock.)
3. Electrical connections must conform to local codes and ordinances, or the National Electrical Code.

4. Wire the luminaire following the wiring diagram on the driver, or inside the box. Use UL listed wire connectors suitable for the size, type, and number of conductors. No loose strands or wires should be present. Secure wire connectors with UL listed electrical tape and wire nuts.

5. Restore electricity and test fixture.

NOTE: These safeguards and instructions are not intended to cover all possible conditions and circumstances. Proceed with caution; utilizing established professional electrical installation methods, tools, and supplies.

### 2) Attach mounting strap to J-box (J-box by others)

Pass wire through locknut.

Secure stem to canopy with lock nut.

Connect black and white wires to line voltage and green to ground.

If applicable, connect purple and gray wires to 0-10V dimming system only, cap off leads if not used.

Attach canopy to mounting strap with finger nuts.

### 1) Open driver housing to access wires and attach Stem.

Pass wire through locknut

Secure stem to housing and re-attach driver housing.

