

CATALOG # : SP2 PENDANTS

SAVE THESE INSTRUCTIONS

WARNING : Before starting installation, turn off power by removing fuses or turning off circuit breakers. Turning off the power by using the light switch is not sufficient to prevent electrical shock. If you feel you do not have electrical experiences needed, have the fixture installed by a qualified licensed electrician.

CAUTION : This is just an installation "guide." Please check with your local certified electrician for proper installation per your city code. We can not be held liable for the use or misuse of the installation guide provided.

Wiring :

1. Mount strap securely to outlet box with 2 pcs of mounting screws provided.
2. Hold the canopy and attach driver BK wire to Supply BK wire; driver WH wire to Supply WH wire with wire connectors provided.
3. Attach Green Ground canopy wire and Supply Green Ground wire to Green Ground screw on strap.
4. Tuck extra wires carefully into box.
5. Fix the canopy to strap by rotating two sets screw on both sides of canopy until it is tight.
6. Rotate the bulb shield on fitting (if bulb shield is not yet rotated on fitting).
7. Turn on the power.

WARNING: DO NOT CUT THE PENDANTS CABLE. LOOP THE CABLE INSIDE THE CANOPY LIKE THE PICTURE SHOWS ON THE RIGHT TO HAVE YOUR DESIRED LENGTH OF CABLE EXPOSING CANOPY.

NOTE : Bulb is free of maintenance and requires no re-lamping.

