








**CAUTION-** INSTALL AND USE THIS LUMINAIRE FOLLOWING YOUR LOCAL ELECTRICAL CODES AND REGULATIONS.

-- READ ALL INSTRUCTIONS

Do not install any luminaire assembly closer than 6" from any curtain, or similar combustible material.

### PREPARATION:

1). Read and understand instructions completely before installing this luminaire. If you are unfamiliar with electrical wiring have a qualified licensed electrician install this luminaire for you.

### ELECTRICAL CONNECTIONS:

- 1). **WARNING-** Before starting the wire connections, disconnect the power by turning off the circuit breaker or removing the fuse at the fuse panel. Turning the power off using the light switch is not sufficient to prevent electrical shock.
- 2). This luminaire must be connected with supply wire rated at 90°C. Most dwellings built before 1985 have supply wire rated at 60°C; consult a qualified electrician before installing.

### INSTALL MOUNTING CROSS BAR:

- 1). Install Mounting Cross Bar using the J-Box Screws, See FIG. A

### MAKE WIRING CONNECTIONS:

- 2). See Wiring Diagram, FIG. B

### INSTALL LUMINAIRE CANOPY:

- 3). Insert Canopy Screws through Canopy Holes, See FIG. C

### FASTENING LUMINAIRE CANOPY:

- 4). Fasten the Canopy using two Nuts, See FIG. D

### FINAL INSTALLATION:

- 5). Luminaire is rotatable and Track Head is adjustable, See FIG. E